

ARBOR REMOVAL FOR EQ35

- 1) You will need a 19mm and a 22mm wrench.
- 2) Loosen two screws at bottom of steady.
- 3) Take the 19mm wrench and attach it to the two flats at the top of the arbor.
- 4) Take the 22mm wrench and attach it around the nut at the bottom of the motor.
- 5) Twist both wrenches in opposite directions and this will loosen the arbor
- 6) Twist off arbor.

****Secure machine in vice and secure the 19mm wrench and take a hammer and hit 22mm wrench in opposite direction.